

**ATTACHMENT TO FORM C-105
COLLINS & WARE, INC.
WOOD, EUGENE #9**

26. Perforation Record.

7935 - 8020 (340 shots)	9/48
7950 - 7995 (180 shots)	9/48
6418 - 6445 (108 shots)	9/48
6445 - 6450 (20 shots)	9/48
6403 - 6418 (60 shots)	9/48
6370 - 6390 (80 shots)	9/48
6234 - 6346 (46 holes)	2/75
4000 (2 holes)	7/75
3340 (2 holes)	7/75
2780 (2 holes)	12/79
5433 - 5854 (97 holes)	10/96

27. Treatment Record.

7935 - 8020	AT w/5000 gals Western 15% acid.
7950 - 7995	AT w/10,000 gals Western 15% low tension acid.
7850	Set cement retainer at 7850'. Squeezed with 81 sx of cement.
6418 - 6445	AT w/1000 gals Western 15% acid.
6482	Spotted 28 gallons pea gravel 6482 - 6454. Spotted 14 gals plastic cap on top of gravel. PBTd 6445. Drilled out.
6441 - 6450	PB with Dowell plastic from 6450 - 6441 with 20 gals of plastic. PBTd 6441.
6403 - 6418	AT w/500 gals Dowell 15% low tension acid. 9/48
6403 - 6418	AT w/1000 gals Western 15% acid.
6370 - 6390	AT w/1000 gals Dowell low surface tension acid.
6360	Set CIBP at 6360 with 5' of sand on top. 2/75
6234 - 6346	AT w/3000 gals 15% NEA acid.
6234 - 6346	FT w/40,000 gals Terra-Frac 20 and 46,500# 20/40 sand. 2/75
4400	Set RBP at 4400' with 4 sx sand on top. Squeeze 4000' with 400 sx cement.
3340	Squeeze perfs with 200 sx cement. 7/75
2780	Squeeze with 450 sx cement.
6234 - 6346	AT w/8000 gals 20% acid. 5/81
6445	Knocked BP free at 6360' and pushed to 6445'. 12/82
6200	Set CIBP at 6200' with 35' of cement on top. 10/96
5433 - 5854	AT w/4000 gals 15% Ferchek SC acid.
5433 - 5854	FT w/98,000 gals 25# Delta Frac using 275,000# 16/30 Ottawa sand. 10/96