

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.O.S.		
LAND OFFICE		
OPERATOR		

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <u>Water Injection Well</u>		7. Unit Agreement Name <u>Penrose Langlie Mattix Sand Unit</u>
2. Name of Operator <u>Anadarko Production Company</u>		8. Farm or Lease Name <u>Tract 4</u>
3. Address of Operator <u>P.O. Box 806 Eunice, New Mexico 88231</u>		9. Well No. <u>1</u>
4. Location of Well UNIT LETTER <u>L</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>22</u> TOWNSHIP <u>22S</u> RANGE <u>37E</u> NMPM.		10. Field and Pool, or Whdcat <u>Langlie Mattix</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>3353' GR</u>		12. County <u>Lea</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

1. RUPU & Reverse Circulation Unit. Pull tbg & pkr.
2. TIH w/bit DC & 2-7/8" tbg.
3. Clean out to TD of 3680'.
4. TOH w/bit, DC & 2-7/8" tbg. TIH w/injection string & pkr. RDPU.
5. Place back on injection.
6. Monitor injection rate for several days & if necessary acidize open hole (3370-3680) w/15% HCL NEFE.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Howard C. Zickert TITLE Field Foreman DATE July 18, 1983

ORIGINAL SIGNED BY EDDIE SEAY

APPROVED BY OIL & GAS INSPECTOR TITLE _____ DATE JUL 20 1983

CONDITIONS OF APPROVAL, IF ANY: