

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT TO DRILL" FORM C-101 FOR SUCH PROPOSALS.)

OIL WELL ☐ GAS WELL ☒ OTHER ☐

1. Name of Operator
Gulf Oil Corporation

2. Address of Operator
P. O. Box 670, Hobbs, NM 88240

3. Location of Well
UNIT LETTER K 1980 FEET FROM THE South LINE AND 1980 FEET FROM THE West LINE, SECTION 23 TOWNSHIP 22S RANGE 37E N.M.P.M.

7. Unit Agreement Name

8. Farm or Lease Name
O. I. Boyd

9. Well No.
3

10. Field Name or Wildcat
Drinkard Blinebry

11. Elevation (Show whether DF, RT, GR, etc.)
3330' GL

12. County
Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

TEMPORARILY ABANDON ☐

PULL OR ALTER CASING ☐

PLUG AND ABANDON ☐

CHANGE PLANS ☐

OTHER Perf 7" casing, circulate cement to eliminate pressure ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

COMMENCE DRILLING OPNS. ☐

CASING TEST AND CEMENT JOB ☐

OTHER ☐

ALTERING CASING ☐

PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

POH with tubing. Set RBP at 5200'; pressure test RBP & casing to 1000#. Circulate hole with 10# brine. Cap RBP with 20' frac sand. Perf at 2880' with (4) 1/2" JH. Establish circulate down 7" casing and out 7" - 9-5/8" casing annulus with 10# brine. Set cement retainer at 2805'; re-establish circulation down tubing and out 7" - 9-5/8" annulus. Cement with 525 sacks Class "C" cement + 2% CaCl₂. Circulate cement; if cement does not circulate, run temperature survey for TOC. Pull out of cement retainer, reverse excess cement. Drill up retainer and cement. Circulate 2% KCL water + adomal to circulate sand off RBP. Recover RBP. Rerun 2-3/8" tubing & 2-1/16" tubing as before. Swab both zones.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R.D. Pate TITLE Area Engineer DATE 9-9-80

APPROVED BY John Pate TITLE Area Engineer DATE SEP 10 1980

CONDITIONS OF APPROVAL, IF ANY: