

REMEDIAL CEMENTING PROCEDURE  
BOYD NO. 5  
510' FHL & 1900' FEL  
SEC. 23, T-22-S, R-37-E  
DRINKARD & TUBB GAS FIELDS  
LEA COUNTY, NEW MEXICO

August 6, 1975

Page Three

shifting tool, run pulling tool, and pull blanking tool. Swab Drinkard zone to flow.

15. Place well on production, producing Drinkard through tubing and Tubb through the annulus.

MLS:cs

cc: West Area

W. C. Young