

Baker "A"
Well No. 1
LaB County, New Mexico

Pull tools, drill out cement and clean hole to top of bridge plug. Test cement job to 1500#. Retrieve bridge plug, rerun tubing with packer and acidize Drinkard perfis. 6380-6413' with 1000 gals 15% NE acid. Pull tubing and packer, run tubing, pump and rods and resume producing well.