

- 9) Set packer at 3440'.
- 10) Breakdown formation.
- 11) Pull packer.
- 12) Frac perforations 3488-3566' with 15,000 gallons of Waterfrac 20, 22,500# 20/40 sand, 450# Adomite Aqua, 15 gallons of NE Agent, in two stages.
- 13) Pull bridge plug at 3580'.
- 14) Run tubing and rods, and commence producing well from Queen (Penrose Sand) perforations 3488-3647'.

- 9) Set packer at 3440'.
- 10) Freshen formation.
- 11) Pull packer.
- 12) Run perforations 3488-3566' with 15,000 gallons of waterflood 20, to 200# 2.140 sand, 450# Atlantic Aqua, 15 gallons of AB Agent, to the stage.
- 13) Pull tubing plug at 3580'.
- 14) Run tubing and rods, and commence producing well from Queen (Grosbeak sand) perforations 3487-3547'.