

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Injection well	7. Lease Name or Unit Agreement Name Langlie Mattix Penrose Sand Unit Tract 28
2. Name of Operator Anadarko Petroleum Corporation	8. Well No. 3
3. Address of Operator P.O. Box 806 Eunice, NM 88231	9. Pool name or Wildcat Langlie Mattix Sand Unit
4. Well Location Unit Letter F : 2310 Feet From The North Line and 2970 Feet From The East Line Section 28 Township 22S Range 37E NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) NA	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: Repair hole in casing <input checked="" type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. RUPU & unseat PKR. TOH w/ inj. tbgs & PKR.
2. TIH w/ PKR & RBP. Set RBP @ 3200'
3. Locate hole in csg.
4. Cement w/ Class "C" w/ 2% CaCl.
5. RURU. Drill out cement & test to 1000#, if test fails repeat steps 3, 4, & 5. If test O.K., TOH w/ bit & drill string.
6. TIH for RBP.
7. TIH w/ PKR & inj. tbgs. Circ PKR fluid. Set PKR @ 3220'.
8. RDPU.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Gerald Ziebart TITLE Field Foreman DATE 5-15-90
TYPE OR PRINT NAME Gerald Ziebart TELEPHONE NO. 394-3184

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON
APPROVED BY DISTRICT I SUPERVISOR TITLE _____

CONDITIONS OF APPROVAL, IF ANY:

MAY 17 1990