

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>

5. State Oil & Gas Lease No.  
**Not available**

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name <b>Langlie Mattix Penrose Sand Unit</b>
2. Name of Operator <b>Anadarko Production Company</b>	8. Farm or Lease Name <b>Tract # 29</b>
3. Address of Operator <b>P. O. Box 247, Hobbs, New Mexico 88240</b>	9. Well No. <b>3</b>
4. Location of Well UNIT LETTER <b>A</b> <b>990</b> FEET FROM THE <b>North</b> LINE AND <b>330</b> FEET FROM THE <b>East</b> LINE, SECTION <b>29</b> TOWNSHIP <b>22 S</b> RANGE <b>37 E</b> NMPM.	10. Field and Pool, or Wildcat <b>Langlie Mattix</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>Not available</b>	12. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☐  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in and rig up well servicing unit and reverse circulation equipment.
2. Clean out to total depth of 3690' through 7" casing using reverse circulation equipment.
3. Caliper open hole from 3423' to 3690'.
4. Set a calseal bridge near 3500'.
5. Run approximately 3500' 5-1/2" 14.00# J-55 casing.
6. Cement 5-1/2" inside of 7" using 50 sacks of cement.
7. Drill out calseal bridge.
8. Run pumping equipment and put well on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE District Superintendent DATE 3/28/68

APPROVED BY [Signature] TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY: