

Form C-103

Skelly Penrose "B" Unit Well No. 10

Page 2

- 6) Load casing annulus behind tubing with water treated with inhibitors.
- 7) Hook well to injection system and resume injection.
- 8) After 30 days, rerun profile survey.