

Form C-103

Skelly Penrose "B" Unit Well No. 5

Page 2

- 5) Load casing annulus behind tubing with water treated with inhibitors.
- 6) Hook well to injection system and resume injection.
- 7) After 30 days, rerun profile survey.