

Form 1160-5
(July 1989)
(Formerly 7-311)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

(CONTACT RECEIVING OFFICE FOR NUMBER OF COPIES REQUIRED)
(Other instructions on reverse side)

PH Russell District
Modified Form No.
NDEO-3160-4

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)

1. ☒ OIL, ☐ GAS, ☐ OTHER		2. NAME OF OPERATOR Lanexco, Inc.		3a. Area Code & Number No. 505-395-3056		3. LEASE DESIGNATION AND SERIAL NO. L-0305-7 A	
4. ADDRESS OF OPERATOR P.O. Box 1206 Jal, NM 88252		5. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1980' FNL & 1980 FWL		6. UNIT ASSIGNMENT NAME		7. FARM OR LEASE NAME Farney A-17	
14. PERMIT NO.		15. SURVEYOR (Show whether of, by, or, etc.) 3478 KB		8. WELL NO. 1		9. FIELD AND POOL, OR WILDCAT Jalmat Tansill Y 7 R	
				10. SEC., T., R., N., OR BLK. AND SUBST. OR AREA S-17, T-23-S, T-36-E		11. COUNTY OF PARISH OR STATE Lea NM	

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	☐	WATER SHUT-OFF	☐
FRACTURE TREAT	☐	FRACTURE TREATMENT	☐
SHOOT OR ACIDIZE	☐	SHOOTING OR ACIDIZING	☐
REPAIR WELL	☒	(Other)	☐
(Other) Repair casing leaks	☐		
PTTL OR ALTER CASING	☐	REPAIRING WELL	☐
MULTIPLE COMPLETE	☐	ALTERING CASING	☐
ABANDON*	☐	ABANDONMENT*	☐
CHANGE PLANS	☐		

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. WORKING PROPOSED OR COMPLETED OPERATIONS (If only state all pertinent details, and also pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perforated in this work.)

Repair holes in 8 5/8 casing in cellar with a welder. Move in rig up unit. Run bridge plug to 1800+- and set. (Top of cement 1725). Isolate the hole in the 5 1/2 casing with a packer. After hole is isolated mix cement and circulate to the surface between 8 5/8" and 5 1/2" casing. Then close in the braden head and squeeze. Wait on cement for 24 hours. and retest casing to 500 psi.

RECEIVED

Aug 10 1990

I hereby certify that the foregoing is true and correct

SIGNED

Mike [Signature]

TITLE Production Supt.

DATE 8-27-90

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

8 5 90

*See Instructions on Reverse Side