

NEFE Acid in 4-stages using 300# rock salt between stages. Flush.

10. Retrieve pkr @ RBP.

11. Install pumping equipment. Test & Return to production.