

- c. WOC for 12 hrs, run temp. survey to find TOC
- ⑧ Cut off CSG at least 3' below mean ground elevation, build and install P&A marker and rig down.