STATE OF NEW MEXICO IERGY AND MINERALS DEPARTMENT

RGY AND MINERALS DEPARTMEN		
DISTRIBUTION		
BANTA PE		
FILE	1	
U.S.O.S.	4	
LAND OFFICE	↓	
		ł :

OIL CONSERVATION DIVISION

so, or cortes acceived	Revised 10-1-78
DISTRIBUTION SANTA FE, NEW MEXICO 87501	
BANTA TO THE TOTAL THE TOTAL TO THE TOTAL TOTAL TO THE TO	5a, Indicate Type of Lease
U.S.Q.S.	State Fee X
LAND OFFICE	5. State Oil & Gas Lease No.
OPERATOR	THIRD THE
THE PROPERTY OF WELLS	
SUNDRY NOTICES AND REPORTS ON WELLS WE NOT USE THIS FORM FOR PROPOSALS TO DRILL ON TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. " (FORM E-101) FOR SUCH PROPOSALS.)	7, Unit Agreement Name
USE "APPLICATION FOR PLANTY	7, 0111
OIL N SAB OTHER-	8. Farm or Lease Hame
wett Lib	Lou Wortham "C"
Anadarko Production Company	9. Well No.
	1
P. Q. Box 806 Eunice, New Mexico 88231	10. Field and Pool, or Wildcat
occation of Well 2310	Eunice San Andres South
B 330 FEET FROM THE LINE AND FEET	
THE EAST LINE, SECTION 11 TOWNSHIP 22S RANGE 37E	THE THE PARTY OF T
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
22561 CB	Lea
Novice Report of	Other Data
Check Appropriate Box to indicate National SUBSEQUE	JENT REPORT OF:
NOTICE OF INTENTION TO:	
PLUE AND ABANDON REMEDIAL WORK	PLUS AND ABANDONMENT
COMMENCE DRILLING OPHS.	PEGG AND RESIDENCE
CHANGE PLANS CASING TEST AND CEMENT JOB	·
OTHER	
ethen	ludias estimated date of starting any proposed
in the state of th	
. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent autes, the	
WALL SEE HOLE	
were see and any anaduction string.	
1. RUPU TOH w/ production string. 1. RUPU TOH w/ production string. 1. TOH w/ bit.	Spotted 700 gals Zylene
1. RUPU TOH w/ production string. 2. TIH w/ 6½" bit CO scale to 4210'. TOH w/ bit. 3. TIH w/ 7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. 3. TIH w/ 7" RBP & rtts. Pulled RTTS to 3762. Let Zyl	Spotted 700 gals Zylene ene soak 2 hrs. R. U.
1. RUPU TOH w/ production string. 2. TIH w/ 6½" bit CO scale to 4210'. TOH w/ bit. 3. TIH w/ 7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. 3. TIH w/ 7" RBP & rtts. Pulled RTTS to 3762. Let Zyl	Spotted 700 gals Zylene ene soak 2 hrs. R. U.
1. RUPU TOH w/ production string. 2. TIH w/ 6½" bit CO scale to 4210'. TOH w/ bit. 3. TIH w/ 7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. 3. TIH w/ 7" RBP & rtts. Pulled RTTS to 3762. Let Zyl	Spotted 700 gals Zylene ene soak 2 hrs. R. U.
1. RUPU TOH w/ production string. 2. TIH w/ 6% bit CO scale to 4210'. TOH w/ bit. 3. TIH w/ 7° RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. w/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. 4. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 &
1. RUPU TOH w/ production string. 2. TIH w/ 6% bit CO scale to 4210'. TOH w/ bit. 3. TIH w/ 7° RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. w/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. 4. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 &
 RUPU TOH w/ production string. TIH w/ 64" bit CO scale to 4210'. TCH w/ bit. TIH w/ 7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. TIH w/ 7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. W/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110 	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 &
1. RUPU TOH w/ production string. 2. TIH w/ 6% bit CO scale to 4210'. TOH w/ bit. 3. TIH w/ 7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. w/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. 4. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 &
1. RUPU TOH w/ production string. 2. TIH w/ 6% bit CO scale to 4210'. TOH w/ bit. 3. TIH w/ 7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. w/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. 4. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 &
1. RUPU TOH w/ production string. 2. TIH w/ 6% bit CO scale to 4210'. TOH w/ bit. 3. TIH w/ 7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. w/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. 4. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 &
1. RUPU TOH w/ production string. 2. TIH w/ 6% bit CO scale to 4210'. TOH w/ bit. 3. TIH w/ 7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. w/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. 4. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 &
1. RUPU TOH w/ production string. 2. TIH w/ 6% bit CO scale to 4210'. TOH w/ bit. 3. TIH w/ 7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. w/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. 4. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 &
1. RUPU TOH w/ production string. 2. TIH w/ 6% bit CO scale to 4210'. TOH w/ bit. 3. TIH w/ 7° RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. w/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. 4. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 &
1. RUPU TOH w/ production string. 2. TIH w/ 6% bit CO scale to 4210'. TOH w/ bit. 3. TIH w/ 7° RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. w/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. 4. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 &
1. RUPU TOH w/ production string. 2. TIH w/ 6% bit CO scale to 4210'. TOH w/ bit. 3. TIH w/ 7° RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. w/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. 4. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 &
 RUPU TOH w/ production string. TIH w/64" bit CO scale to 4210'. TCH w/ bit. TIH w/7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. TIH w/ 79 RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. W/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110 5 gals. RP2336. RU Swab. Swabbed back @ 80 BLW. TOH w/ RTTS & RBP. RU Swab. Swabbed back @ 80 BLW. TOH w/ RTTS & RBP. TIH w/ production string & set SN. @ 4208. Ran 2½ X 1 3/4 X 	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 &
 RUPU TOH w/ production string. TIH w/64" bit CO scale to 4210'. TCH w/ bit. TIH w/7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. TIH w/ 79 RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. W/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110 5 gals. RP2336. RU Swab. Swabbed back @ 80 BLW. TOH w/ RTTS & RBP. RU Swab. Swabbed back @ 80 BLW. TOH w/ RTTS & RBP. TIH w/ production string & set SN. @ 4208. Ran 2½ X 1 3/4 X 	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 & 12' X 16' pump. POP. RD PU.
 RUPU TOH w/ production string. TIH w/ 6½" bit CO scale to 4210'. TOH w/ bit. TIH w/ 7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. w/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110 5 gals. RP2336. RU Swab. Swabbed back @ 80 BLW. TOH w/ RTTS & RBP. TIH w/ production string & set SN. @ 4208. Ran 2½ X 1 3/4 X TIH w/ production string & set SN. @ 4208. Ran 2½ X 1 3/4 X 	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 & 12' X 16' pump. POP. RD PU.
 RUPU TOH w/ production string. TIH w/ 6½" bit CO scale to 4210'. TCH w/ bit. TIH w/ 7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. w/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110 5 gals. RP2336. RU Swab. Swabbed back @ 80 BLW. TOH w/ RTTS & RBP. RU Swab. Swabbed back @ 80 BLW. TOH w/ RTTS & RBP. TIH w/ production string & set SN. @ 4208. Ran 2½ X 1 3/4 X 	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 & 12' X 16' pump. POP. RD PU.
1. RUPU TOH w/ production string. 2. TIH w/6½" bit CO scale to 4210'. TOH w/ bit. 3. TIH w/ 7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. w/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. 4. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110 5 gals. RP2336. 5. RU Swab. Swabbed back @ 80 BLW. TOH w/ RTTS & RBP. 6. TIH w/ production string & set SN. @ 4208. Ran 2½ X 1 3/4 X TIH w/ production string & set SN. @ 4208. Field Foreman	Spotted 700 gals Zylene ene scak 2 hrs. R. U. gals. Tretolite SP260 & 12' X 16' pump. POP. RD PU.
1. RUPU TOH w/ production string. 2. TIH w/6½" bit CO scale to 4210'. TCH w/ bit. 3. TIH w/7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. w/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl swab. Swab back @ 90 Bbls. wtr. 4. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110 5 gals. RP2336. 5. RU Swab. Swabbed back @ 80 BLW. TOH w/ RTTS & RBP. 6. TIH w/ production string & set SN. @ 4208. Ran 2½ X 1 3/4 X 6. Libereby certify that the infernation above is true and complete to the best of my knowledge and belief. Libereby certify that the infernation above is true and complete to the best of my knowledge and belief. Field Foreman	Spotted 700 gals Zylene ene soak 2 hrs. R. U. gals. Tretolite SP260 & 12' X 16' pump. POP. RD PU.
 RUPU TOH w/ production string. TIH w/ 6½" bit CO scale to 4210'. TCH w/ bit. TIH w/ 7" RBP & RTTS. Set RBP @ 4200. Test RBP 1000# O.K. w/ 190 gal. fresh water flush. Pulled RTTS to 3762. Let Zyl. swab. Swab back @ 90 Bbls. wtr. RU Halliburton and treated w/ 3800 gals 20% NeFe Acid w/ 110 5 gals. RP2336. RU Swab. Swabbed back @ 80 BLW. TOH w/ RTTS & RBP. TIH w/ production string & set SN. @ 4208. Ran 2½ X 1 3/4 X TIH w/ production string & set SN. @ 4208. Ran 2½ X 1 3/4 X 	Spotted 700 gals Zylene ene scak 2 hrs. R. U. gals. Tretolite SP260 & 12' X 16' pump. POP. RD PU.