

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

- 16.

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

- Run 2 7/8" tubing to 4508' & set 60 sks cmt w/ 60 bbls. mud ahead of cmt.
 Tagged top of cmt @ 4245'. Cut 8 5/8" csq @ 3036' & salvaged.
 Set tubing @ 3416' & circ hole w/ mud. Set 150 sks. cmt @ 3416'
 & pulled tubing to 689'. Set 100 sks Class 'c' cmt. Tagged
 cmt plug @ 420'. Set 10 sks cmt. plug @ sfc. & installed
 dry hole marker. Work started 12-16-74, completed 12-23-74.

DATE _____

TITLE

DATE _____

***See Instructions on Reverse Side**