

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

CIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

3a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator Gulf Oil Corporation		8. Farm or Lease Name H. T. Mattern (NCT-D)
3. Address of Operator P. O. Box 670, Hobbs, NM 88240		9. Well No. 12
4. Location of Well UNIT LETTER <u>EK</u> , <u>2130</u> FEET FROM THE <u>South</u> LINE AND <u>1860</u> FEET FROM THE <u>West</u> LINE, SECTION <u>6</u> TOWNSHIP <u>22S</u> RANGE <u>37E</u> NMPM.		10. Field and Pool, or Wildcat Blinebry
15. Elevation (Show whether DF, RT, GR, etc.) 3454' GL		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>DHC Blinebry, Tubb & Drinkard (R-7238)</u> <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

POH with production equipment. Drill out CIBP at 6100' and push below bottom Drinkard perf as far as possible. Acz Tubb and Drinkard with 5000 gals 15% NEFE HCL, (108) RCNB's, rock salt and benzoic acid. Close in well 1 hr; open well and swab. GIH with 2-3/8" tubing. RIH with pump and rods. Hang well on. Kick off.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED RR Pitre TITLE Area Engineer DATE 4-28-83

ORIGINAL SIGNED BY JERRY SEXTON

APPROVED BY DISTRICT SUPERVISOR
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

MAY 2 1983

RECEIVED
APR 29 1983
HOBBS OFFICE