

ADD PROGRAM

<u>DEPTH INTERVAL FROM-TO</u>	<u>WEIGHT LBS/CAL</u>	<u>TYPE</u>	<u>OIL %</u>	<u>PH</u>	<u>WATER LOSS (cc)</u>	<u>VIS. (sec.)</u>	<u>YIELD POINT</u>	<u>THINNING AGENTS</u>	<u>WATER LOSS AGENTS</u>
0' - 1600'	8.5 - 9.0	spud mud							
1600' - 3880'	9.0 - 10.0	salt gel			10-14	34-38			gel & starch

REMARKS

* Drill out with brine water. Add sufficient gel to carry cuttings.

Condition mud to lower viscosity prior to cementing.