

10. Acidize perms 3834'-44' with 5000 GA-20% HCL.
11. Swab in to flow. Place on production.