

November 1983)
formerly 9-331)

UNITED STATES OF AMERICA
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Project Number No. 1004-0135
Expires August 31, 1985
LEASE DESIGNATION AND SERIAL NO.
NM-19620
IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR Happy Happy Oil Company	8. FARM OR LEASE NAME Triste Draw Fed.
3. ADDRESS OF OPERATOR P.O. Box 343, Artesia, N.M. 88210	9. WELL NO. #1
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface Unit N,660' from the SL, and 1980' from the WL, Section 11, Township 23S, Range 32E N.M.P.M.	10. FIELD AND POOL, OR WILDCAT Diamondtail bn Spring
14. PERMIT NO.	11. SEC., T., R., M., OR BLM, AND SURVEY OR AREA Sect: 11 T23S, R32E
15. ELEVATIONS (Show whether of, to, or, etc.) 3728 GR	12. COUNTY OR PARISH 13. STATE Lea NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☐
☐
☐

FRACURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

Re-Entry

BLM Approved 10-31-86

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐
☐
☐

FRACURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐
☐
☐

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all members and zones pertinent to this work.)

11-4-86 Run tbg to 450'. Pickup swivel and drill hard cement to 500'. Pick up tbg and tag next plug @ 1180'. Drill very hard cement down to 1210'. Circ. clean and SIFN. Progress 1020'

11-5-86 Continue drilling very hard cement to 1225'. Work on pump. Replace swivel packing. Getting small amount of iron in samples. Test head and BOP to 1500 PSI OK or 30 min. Progress 15' TD 1225' SIFN

11-6-86 TOHW tbg. change out bit. New Bit 6-1/4" blade bit. TIH and start drilling very hard cement. Drill 8' in 2-1/2 hrs. TOH and pick up 2 additional 4-3/4 collars. For total of 8. TIH & drill to 1365'. Pickup tbg to 2500' circ clean and SIFN. Progress 1225' TD 2500'

11-7-86 Drill hard cement to 2992'. Turn over to night crew. Drill all night. Drill cement to 3021'. Run tbg to 6970'. Drill to 7064'. Progress 4564' TD 7064'.

ACCEPTED FOR RECORD

DEC 09 1986

CARLSBAD, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

Diana Plots

TITLE

Office Manager

DATE

11-20-86

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side