

ATTACHMENT I

Commingling Procedure
Item 12 continued

9. NU wellhead w/tbg in 12,000# tension.
10. RIH w/pump on 7/8" & 3/4" rods. Seat pump, space out well and hang on.
11. Load and test tubing.
12. NU wellhead.
13. RD pulling unit.
14. Place well on test pumping to battery.