

COMPLETION PROCEDURE:

1. Back drag the location and set pulling unit anchors.
2. Move in and rig up a pulling unit.
3. Trip in the hole with a retrieving head on 2-7/8" tubing. Retrieve the plug. Trip out of the hole and lay down the plug. Trip in the hole with a retrievable packer on packer and set at +/- 8000'.
4. Swab/flow test well.

