

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-062749(b)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

CONTINENTAL OIL COMPANY

3. ADDRESS OF OPERATOR

Box 460, HOBBS, N.M. 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)At surface
1980' FNL & 660' FWL of Sec. 19

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

THOMPSON 19 FEDERAL

9. WELL NO.

10. FIELD AND POOL, OR WILDCAT

MASON DELAWARE NORTH

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 19, T-26S, R-32E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3201' DF

12. COUNTY OR PARISH

LEA

13. STATE

N.M.

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

INSTALL LINER

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING


ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertain-
ent to this work.)*

In order to reduce sand production and damage to producing equipment, the following procedure is proposed: Run 188' of 2 3/8" OD Liner including 60' of screen & 2' of telltale screen, crossover tool & pkr as shown on attached schematic. Run Baker Retrieval-D GP Pkr w/extensions & screen. Set pkr & test. Set tool in squeeze position & pump 1000 gals 20% KCL wtr. Set tool in circulating position & Terra-Pack as follows: Pump 3 bbls Terra-Pack fluid w/o sd. Pump 10 bbls Terra-Pack slurry w/ 15#/gal of 20-40 sd. Follow w/ 3 bbls Terra-Pack fluid w/o sd. Displace w/ salt wtr to force gravel in place until tell-tale screen is covered. Reverse out Terra-Pack slurry remaining in tubing & retrieve setting tool. Run Prod. Eqp.

18. I hereby certify that the foregoing is true and correct

SIGNED



TITLE

SR. ANALYST

DATE

7-16-74

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED

JUL 17 1974

ARTHUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse Side

USGS-5, file

PROPOSED INSTALLATION
THOMPSON FED. 19 No. 1

