

9. Run 2-3/8" tubing CA and on-off tool. Space out and circulate v., 2% KCL water. Latch on-off tool and ND BOPE. NU tree. Swab fluid level down to 2750' and than pull blanking plug. Flow well to clean up.
10. TOTPS.

*MW Gore*

M. W. Gore

*MW/MEE* *J.E.*

Concur: M. E. Ellis J. E. Shields