

UNIT STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPPLICATE
(Other instructions on
reverse side)Form approved,
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 030139(a)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. ☐ OIL WELL ☐ GAS WELL ☐ OTHER ☒ Plug & Abandon	7. UNIT AGREEMENT NAME NMFU			
2. NAME OF OPERATOR CONTINENTAL OIL COMPANY	8. FARM OR LEASE NAME LYNN A			
3. ADDRESS OF OPERATOR Box 460, Hobbs, NM 88240	9. WELL NO. 7			
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 660' FNL & 660' FEL OF Sec. 28	10. 7 RIVERS (SWD) - 500' JALMAT YATES 625			
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3431' DF	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 28, T. 23S, R. 36E	12. COUNTY OR PARISH Lea	13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

Due to the lack of Reserves and deteriorated downhole conditions, IT IS Proposed to P & A This Well By The Following Procedure:

1. Circulate and Load Hole with 10# Brine
2. Set Retainer AT 2850' and Squeeze with 150 SX Class "C" CMT w/ 2% CACL
3. SPOT 5 SX Class "C" CMT ON TOP OF Retainer.
4. Pull out of Hole, Remove Stinger, Run Tbg in Hole open ended.
5. SPOT 20 SX Class "C" CMT Plug From 1510' TO 1392'.
6. SPOT 20 SX Class "C" CMT Plug From 400' TO 282'.
7. SPOT 10 SX Class "C" CMT From Surface TO 59'.
8. Eject Dry Hole Marker and Restore The Surface.

See Attached Well History and Recommendation.

18. I hereby certify that the foregoing is true and correct.

SIGNED

W. A. Butterfield

TITLE

ADJ. SURV. DATE 12-15-76

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

*See Instructions on Reverse Side

USGS-5, NMFU-4, File

ARTHUR R. BROWN
SENIOR ENGINEER