

LEWIS BURLESON, INC
WELLBORE DIAGRAM

WELL NAME Stevens A-34 #2

7 5/8 SURFACE @ 1309
SACKS & TYPE 500SX Circulated

Top of
Salt 1400

DATE NOTES Plugging Procedure

1) Install Bop

2) Set CIBPE 3000 Cap with
100' Plug

3) Circulate hole with Mud

4) Set Plug from 1300-1400
Covering shoe + top of salt

5) Set 100' Plug at Surface

6) Install Marker, clean and
restore location

Base of
Salt @
3010

5 1/2 PRODUCTION @ 3024
SACKS & TYPE 500SX Circulated