## N. M. UIL GUNS. GUMMISSIUN P. O. BOX 198' HOBBS, NEW M.\_AICO 88240

	110000, NL	LIF MEXICO 60240
	O+5 - USGS - P.O. Box 1857 1 - Engr	Form Approved
	Form 9-331 Roswell, NM 88201 l - Foreman	HC 1 - FileBudget Bureau No. 42-R1424
	UNITED STATES	5. LEASE O
	DEPARTMENT OF THE INTERIOR	LC-03 <b>X</b> 467 (a)
	GEOLOGICAL SURVEY	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
	CHARDY NOTICES AND DEDORTS ON WELLS	7. UNIT AGREEMENT NAME
	SUNDRY NOTICES AND REPORTS ON WELLS	
	(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9–331–C for such proposals.)	8. FARM OR LEASE NAME
#16 	1. oil gas other Injection well	9. WELL NO.
	2. NAME OF OPERATOR	206
	Getty Oil Company	10. FIELD OR WILDCAT NAME
	3. ADDRESS OF OPERATOR	Ianglie Mattix
<del>4.</del> 6	P.O. Box 730 Hobbs, NM 88240	11. SEC., T., R., M., OR BLK. AND SURVEY OR
	4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17	AREA 2
	below.) Unit ltr. E, 1980 FNL & 660' FWL	Sec 12, TX4S, R36E
	AT SURFACE:	12. COUNTY OR PARISH 13. STATE
	AT TOP PROD. INTERVAL:	IeaNM
•	AT TOTAL DEPTH:	14. API NO.
ria.	16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE,	
	REPORT, OR OTHER DATA	15. ELEVATIONS (SHOW DF, KDB, AND WD)
-4	· · · · · · · · · · · · · · · · · · ·	
***	REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:	DF=3358, KB=3359, GR=3348
	TEST WATER SHUT-OFF	
* *	FRACTURE TREAT	
ry r	SHOOT OR ACIDIZE □ □ STREET	10/19/10
	REPAIR WELL XX	(NQTE) Report results of multiple completion or zone
	PULL OR ALTER CASING	change on Form 9-330.)
	MULTIPLE COMPLETE	1002
· · ·	CHANGE ZONES	1982 AU 1982 A 1945 E
	ABANDON*	
	(other) temporarily abandon OR & G	aas
gsal. General	Jarglie Walter 45 GEOLOGIC	
4.4/	17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state	te all pertinent details, and give pertinent dates.
	including estimated date of starting any proposed work. If well is a measured and true vertical depths for all markers and zones pertine	directionally drilled, give subsurface locations and
	measured and true vertical depths for all markers and zones pertine	The to this workly
	1. Rig up pulling unit and install BOP.	
84		
	3. Pull tubing (Ianglie Mattix and Jalmat).	
	4. Set plug in Model "D" packer at 3400' an	
	temporarily abandoning Langlie Mattix zo	one.
	5. Run CBL-GR-CCL and perf 2 holes at TOC.	
	6. TIH with workstring and retainer and squ	meeze channel behind intermediate
r.mid=19p	casing.	
en e		
er der		it doment in acc. to DDD
indiag and g≱v f	8. TIH with workstring and bit and drill ou	
e ge Se sage Seggi	9. Test squeeze to 500# using bit and BOP.	POH.
	10. Retreive RBP and run Jalmat tubing.	en e
	11. Swab Jalmat to production.	
* . * :	Subsurface Safety Valve: Manu. and Type	Set @ Ft.
	10 11 Aid, that the favoration is two decorate	
	18. I hereby certify that the foregoing is true and correct	·
	SIGNED CONTROL TITLE Area Superint	tendent October 25, 1982
	Dale R. Crockett	
$\mathcal{D}$	APPROVE Whis space for Federal or State of	ffice use)
7		
,wa R1	APPROVED ( APPROVAL, IF ANY:	DATE
	CONDITION'S OF APPROVAL, IF ANY:	
	NOV 1 6 1982	
ele Tr	FOR	
ing the second s	JAMES A. GILLHAM  DISTRICT SUPERVISOR  DISTRICT SUPERVISOR	Side
	DISTRICT SUPERVISOR	
	L	

-9-8-6