

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPL  
(Other instructions  
verse side)

"E"  
re-

Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

**LC-032452 (A)**

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

**SUNDRY NOTICES AND REPORTS ON WELLS**

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL ☒ GAS ☐  
WELL ☒ WELL ☐ OTHER

2. NAME OF OPERATOR

**Skelly Oil Company**

3. ADDRESS OF OPERATOR

**P. O. Box 1351, Midland, Texas 79701**

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

**Unit Letter "P", 660' FSL and 660' FSL Section 9-23S-37E**

7. UNIT AGREEMENT NAME

**Skelly Penrose "A" Unit**

8. FARM OR LEASE NAME

**Skelly Penrose "A" Unit**

9. WELL NO.

**59**

10. FIELD AND POOL, OR WILDCAT

**Langlie-Mattix**

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

**Sec. 9-23S-37E**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

**3295.5' GR**

12. COUNTY OR PARISH

**Lea**

13. STATE

**New Mexico**

16.

**Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data**

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

PULL OR ALTER CASING ☐

FRACTURE TREAT ☐

MULTIPLE COMPLETE ☐

SHOOT OR ACIDIZE ☐

ABANDON\* ☐

REPAIR WELL ☐

CHANGE PLANS ☐

(Other) **Convert to water injection**

☒

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

REPAIRING WELL ☐

FRACTURE TREATMENT ☐

ALTERING CASING ☐

SHOOTING OR ACIDIZING ☐

ABANDONMENT\* ☐

(Other) ☐

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

- 1) Move in pulling unit. Pull rods and tubing.
- 2) Clean out to 3640' TD.
- 3) Run 2-3/8" OD internally plastic coated tubing.
- 4) Circulate with water treated with corrosion inhibitors.
- 5) Set packer at approximately 3450'.
- 6) Connect to injection system and commence injection.

18. I hereby certify that the foregoing is true and correct

SIGNED

**D. R. Crow**

TITLE

**Lead Clerk**

DATE

**12/7/73**

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

DATE

\*See Instructions on Reverse Side

## Instructions

**General:** This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

**Item 4:** If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

**Item 17:** Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.