

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPL
(Other instructions re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.
LC-032452 (a)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. ☐ OIL WELL ☐ GAS WELL ☐ OTHER **Water Injection Well**

2. NAME OF OPERATOR
Skelly Oil Company

3. ADDRESS OF OPERATOR
P. O. Box 1351, Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface
1650' FSL and 330' FWL Sec. 10-23S-37E

7. UNIT AGREEMENT NAME
Skelly Penrose "A" Unit

8. FARM OR LEASE NAME
Skelly Penrose "A" Unit

9. WELL NO.
55

10. FIELD AND POOL, OR WILDCAT
Langlie-Mattix

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA
Sec. 10-23S-37E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)
3302' DF

12. COUNTY OR PARISH
Lee

13. STATE
New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐ PULL OR ALTER CASING ☐
FRACTURE TREAT ☐ MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐ ABANDON* ☐
REPAIR WELL ☐ CHANGE PLANS ☐
(Other) **Squeeze off existing perfs. and re-perforate.** ☒

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐ REPAIRING WELL ☐
FRACTURE TREATMENT ☐ ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐ ABANDONMENT* ☐
(Other) ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1) Move in pulling unit. Pull injection tubing and packer.
- 2) Clean out to 3649' PFTD.
- 3) Squeeze off existing perforations 3518-3636'. WOC 24 hours.
- 4) Drill out cement to 3649' PFTD.
- 5) Spot 250 gallons of 7-1/2% acid and perforate with one shot at each of the following places: 3520', 3533', 3540', 3555', 3569', 3582', 3604', and 3615'.
- 6) Treat perforations 3520-3615'.
- 7) Run 2-3/8" OD cement lined injection tubing, circulate with treated water, and set packer at approximately 3449'.
- 8) Connect to injection system and resume injection.

18. I hereby certify that the foregoing is true and correct

SIGNED D. R. Crow

Lead Clerk

DATE 4-30-73

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

ACCEPTED FOR RECORD

MAY 1 1973

**U. S. GEOLOGICAL SURVEY
HOBBS, NEW MEXICO**

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site abandoned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1963-O-685229

847-485

DEPT. OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
WASHINGTON, D.C. 20250