

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPL
(Other instruction
verse side)ATTN:
re-Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

1C 030186(2)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR	NAME
3. ADDRESS OF OPERATOR	8. FARM OR LEASE NAME
Continental Oil Company	CLINE A-15
Box 960, Hobbs, N. Mex.	9. WELL NO.
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface	10. FIELD AND POOL, OR WILDCAT
660' FSL + WL of Sec. 15, T-23S, R-37E,	Primary Pool
in Lea County, N. Mex.	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
14. PERMIT NO.	Sec. 15, T-23S, R-37E
15. ELEVATIONS (Show whether DS, RT, CR, etc.)	12. COUNTY OR PARISH
3308 DF	Lea
	13. STATE
	N. Mex.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT ON:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

It is proposed to deepen & recomplete this well by the following procedures:

1. Squeeze plugs from 3534' to 3594' with 100 sacks of cement.
2. Drill out cement plugs and drill to a new TD of 5800'.
3. Run G.R./N log and run 4 1/2" OD 9.5# casing and set from 3375' to 5800' with 250 sacks of cement.
4. Perforate selected intervals w/1 - 3/8" 15 PF.
5. Treat plugs with 2,000 gals 15% LSTNE. Followed with 60,000 gals water & 60,000# 20-70 fine sand.
6. Run 2 3/8" OD tubing with SN and set at 5720'.
7. Switch well in.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

DATE

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

FILED

28 Jul 5

*See Instructions on Reverse Side

Chas. Mid. - 2, Pan Am Hobbs 2, All. Row 2, Fib.

JUL 10 1968
DISTRICT ENGINEER