Form 3160-5 (June 1990

## UNITED STATES DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT**

FORM APPROVED Budget Bureau No. 1004-0135

Expires: March 31, 1993 5. Lease Designation and Serial No.

## SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or deepen or reentry to a different reservior.

20-0301 6. If Indian, Allottee or Tribe Name

**New Construction** 

Non-Routine Fracturing

Use "APPLICATION FOR PERMIT-" for such proposals		N/A		
SUBMIT IN TRIPLICATE		7. If Unit or CA, Agreement Designation		
1. Type of well  X Oil Gas Other		N/A 8. Well Name and No.		
2. Name of Operator		LA MUNYON FED. (*B) #3		
CHEVRON U.S.A. INC.		9. API Well No.		
3. Address and Telephone No.		30-025-10836		
P.O. BOX 1150 MIDLAND, TEXAS 79702 ATTN: P.R. MATTHEWS, ROOM 4115-A		10. Field and Pool, or Exploratory Area		
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)		LANGLIE MATTIX SR-QN GB		
SEC. 22, T23S, R37E		11. County or Parish, State		
660 FSL & 1980' FEL		LEA COUNTY, NEW MEXICO		
UNIT <b>Ø</b>		,		
CHECK APPROPRIATE	BOX(S) TO INDICATE NATURE OF NOTICE	CE, REPORT, OR OTHER DATA		
12 TYPE OF SUBMISSION	TYPE OF ACTION			
X Notice of Intent	Abandonment	Change of Plans		
	Recompletion	New Construction		

Casing Repair Water Shut-Off Final Abandonment Notice Altering Casing Conversion to Injection Dispose Water s: Report results of multiple completion on Well

Plugging Back

Completion or Recompletion Report and Log form.) 13. Decribe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimate date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

IT IS PROPOSED TO: PLUG & ABANDON WELL

Subsequent Report

TIH & TAG CIBP AT 3500', LOAD HOLE W/FW AND TEST CSG.

SPOT 350' CMT F/3500'-3350', COVERS QUEEN, PENROSE & GRAYBURG.

SPOT 600' CMT F/2910'-2310', COVERS SALT BASE, YATES & 7-RIVERS.

PERF AT 1200', SET CICR AT 1000', SQZ HOLES W/80 SXS. CMT. PULL OUT & LEAVE 35' ON TOP OF CICR.

ABOVE PLUG COVERS RUSTLER & SALT TOP. SPOT 250' F/450'-200', COVERS 10.75" CSG. SHOE.

SPOT 100' OF CEMENT FROM SURFACE TO 100'.

10# P & A MUD WILL BE PLACED BETWEEN ALL CEMENT PLUGS.

CUT OFF WELLHEAD AND INSTALL P & A MARKER.

CHANGE WELL STATUS TO P & A.

I hereby certify the the forgoing is true and correct Signed C. C. Mallace	Title	TECHNICAL ASSISTANT	Date	5/12/92
This space for Federal of State office feel	Mittle		Date 5	-15 92-
Conditions of approval, if any:				

or representations as to any matter within its jurisdiction

RECEIVED
WAY 1 9 1992