

E. E. BLINEBRY B NCT-2 #2

1. Rigged up. Remove Well Head. Install BOP.
2. Set packer @ 3473. Tested 5 1/2" casing W/600#, 5-23-83.
Tested OK.
3. Set CIBP @ 3465'.
4. Install Well Head Equipment. Job Complete 5-23-83.

BUREAU OF LAND MANAGEMENT REPRESENTATIVE WITNESSED TEST

RECEIVED
OCT 5 1983
O.C.D.
HOSES OFFICE