

E. E. BLINEBRY B NCT-4 #1

1. Rigged up. Remove well head. Install BOP.
2. Set packer @ 2731'. Tested 7" Casing W/600#, 5-17-83.
Tested OK.
3. Set CIBP @ 2728.
4. Install Well Head equipment. Job complete 5-18-83.

BUREAU OF LAND MANAGEMENT REPRESENTATIVE WITNESSED TEST

RECEIVED
SEP 7 1983
O.C.D.
HOBBS OFFICE