

Permoc Oil, Inc.
#1 Glen Ryan
Lease NM-7951
660' FSL & 660' FEL sec. 11, T26S., R37E.

Plugging Program

1. Set CIBP at 2646' and cap with 75' cement to cover top of San Andres base of Salt.
2. Perforate 7" casing at 1025' and squeeze with 30 sacks. Leave a 100' plug in casing to extend from 1025' to 925'. Top of salt plug.
3. Perforate 7' casing at 285' and squeeze with sufficient cement to circulate to surface and leave 100' plug from 285' to 185'.
4. Spot 35' plug at surface, cut casing and cap well.

Follow the attached Condition of Approval.