

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☐ Fee ☐
5. State Oil & Gas Lease No.
062384

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- Injection Well	7. Unit Agreement Name So. Leonard Unit
2. Name of Operator TEXAS PACIFIC OIL COMPANY	8. Farm or Lease Name Tract 1
3. Address of Operator P. O. Box 1069 - Hobbs, New Mexico	9. Well No. 1
4. Location of Well UNIT LETTER N , 660 FEET FROM THE South LINE AND 1980 FEET FROM THE West LINE, SECTION 13 TOWNSHIP 26-S RANGE 37-E NMPM.	10. Field and Pool, or Wildcat So. Leonard Queen
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Upon approval, we propose to convert above well to injection well for waterflood.

1. Move in, rig up. Pull rods & tubing. Clean out to 3484'.
2. Log well. Spot 300 gal. NE acid in open-hole. Set packer at 3200'.
3. Acidize w/1500 gal. NE acid. Swab. Run tbg. & pkr. @ 3200'.
4. Connect up well head according to standard injection well head diagram.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed by

Sheldon Ward

SIGNED _____

TITLE **Area Superintendent**

DATE **9-5-68**

APPROVED BY _____

TITLE _____

DATE _____

CONDITIONS OF APPROVAL, IF ANY: