

Plug & Abandonment

Farnsworth No. 19-M Subsequent Report of

The following work was performed to properly plug and abandon the subject well.

- 1). It was reentered and drilled out to 3057'.
- 2). The bottom string of casing is 10-3/4" and was set at 2852' and was shot off at 2026'. A 150 sack cement plug was spotted 2906 - 2658 (248') and tagged at 2658'. For the stub plug 100 sacks cement was spotted 2056-1880' (171' plug) and tagged at 1880'.
- 3). 13" casing was set at 1184' and was shot off at 890'. 300 sacks of cement was spotted 1245'-1080' (165' plug) and tagged at 1080' for the shoe plug. A 150 sack cement plug was spotted 936-750' (186' plug) and tagged at 750' for the stub plug.
- 4). 16" casing was set at 554' and shot off at 494'. 300 sacks were spotted 605-435' (170' plug) and tagged at 435'.
- 5). 100 sacks of cement was spotted for the surface plug. All the cement was class "C" with 2% CaCl₂ and 9.5ppg mud was left between all plugs. A dry hole marker with all appropriate information was set in the surface plug. The pit was filled and the location was leveled and cleared of all junk.