

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

RECEIVED

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: September 30, 1990

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.

Aug 3 10 17 AM '90

5. Lease Designation and Serial No.

C-032510-C

6. If Indian, Allottee or Tribe Name

SN/A

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☐ Gas Well ☒ Other

Water Injection Well

2. Name of Operator

Wood, McShane & Thams

3. Address and Telephone No.

P. O. Box 968, Monahans, Texas 79756 (915)943-7531

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit Letter N, 990' FSL and 1980' FWL

Sec. 24, T-26-S, R-37E

7. If Unit or CA, Agreement Designation

South Leonard Unit

8. Well Name and No.

Tract 4 Well #16

9. API Well No.

Unknown

10. Field and Pool, or Exploratory Area

South Leonard (Queen)

11. County or Parish, State

Lea County, New Mexico

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

PROPOSED PLUGGING PROCEDURE AS DISCUSSED WITH ADAM SALAMEH (BLM): WORK TO BEGIN 7/24/90

1. M.I.R.U. Pulling Unit - P.O.O.H. with 2 3/8" tbg. and packer.
2. T.I.H. on 2 3/8" tbg. with 5 1/2" C.I.B.P. - Set C.I.B.P. @ 3200'.
3. Circulate well with 10#/gal. gelled Brine mud.
4. Spot 50' cement plug from 3200' to 3150' on top of C.I.B.P.
5. Spot 100' cement plug across top of salt @ 1140' - from 1190' to 1090'.
6. Spot 100' cement plug at base of surface csg. shoe @ 291' - from 341' to 241'.
7. W.O.C. and tag plug.
8. Spot 50' cement plug from 50' to surface.
9. Cut off 9 5/8" and 5 1/2" csg. and install dry hole marker.
10. Clean up location - fill in cellar and pit.

14. I hereby certify that the foregoing is true and correct

Signed John R. Dollahan

Title Drilling Foreman

Date 7/23/90

(This space for Federal or State office use)

Approved by John R. Dollahan

Title PETROLEUM ENGINEER

Date 8-7-90

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction

\*See Instruction on Reverse Side