

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

RBD-Shelby Agency (214)508-2323, Fax 3945

3. Address and Telephone No.

P.O. Box 830308, Dallas, Texas 75283-0308

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

S. 31, T26S-R37E: 330' FSL, 990' FEL NE/4

*Unit H*

*30-025-12067*

FORM APPROVED

Budget Bureau No. 1004-0135  
Expires: September 30, 1990

5. Lease Designation and Serial No.

LC 030168-B

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Eaves "B"

9. API Well No.

1

10. Field and Pool, or Exploratory Area

Scarborough Yates *SR*

11. County or Parish, State

Lea, New Mexico

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent  
☒ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other

- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.):

- 1.) Set 6 5/8" cast iron bridge plug at 2750' and capped with 20 sacks cement
- 2.) a. Perforate casing at 1520' squeezed 60 sacks cement with packer and wait on cement  
Run tool to 2000' no tag of cement  
b. Spot 50 sacks cement at 1418' wait on cement run tool and tag cement at 2140'  
c. Spot 50 sacks cement at 1418' wait on cement run tool and tag cement at 2140'
- 3.) Cut and pull 6 5/8" casing at 1340'
- 4.) Set 8 5/8" cement retainer at 1197' and squeezed 50 sacks below and spot 25 sacks on top of cement retainer
- 5.) Spot 85 sacks cement at 283' and circulate to surface, set P.A. marker

Approved as to plugging of the well bore,  
Liability under bond is waived until  
surface restoration is completed,

14. I hereby certify that the foregoing is true and correct

Signed *Betty Blake*

Title *District Clerk*

Date *8-16-92*

(This space for Federal or State office use)

Approved by \_\_\_\_\_  
Conditions of approval, if any:

Title *ENGINEER*

Date *8-16-92*

RECEIVED

JUN 18 1992

200 HOBBS DRIVE