

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION, C. C.

JUL 17 11 57 AM '69

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
B-9312-5

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	8. Farm or Lease Name
3. Address of Operator	9. Well No.
4. Location of Well	10. Field and Pool, or Wildcat
15. Elevation (Show whether DF, RT, GR, etc.)	12. County

UNIT LETTER **B** **810** FEET FROM THE **North** LINE AND **2130** FEET FROM **East** THE **5** LINE, SECTION **25S** TOWNSHIP **38E** RANGE **38E** NMPM.

15. Elevation (Show whether DF, RT, GR, etc.) **Unknown**

12. County **Lea**

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> Convert to water injection

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Move in and rig up pulling unit.
- 2) Pull rods and tubing.
- 3) Run tubing and set packer.
- 4) Rig down and connect to injection system.
- After Reservoir begins to pressure up, then:
- 5) Rig up pulling unit and pull tubing and packer.
- 6) Run tubing with bit and clean out to T. D.
- 7) Pull tubing and bit.
- 8) Run tubing and set packer.
- 9) Fill annulus with inhibited fluid.

ILLEGIBLE

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED	TITLE	DATE
<i>[Signature]</i>	Supervisor Production Mgr	7-15-69
APPROVED BY	TITLE	
<i>[Signature]</i>	SUPERVISOR DISTRICT	
CONDITIONS OF APPROVAL, IF ANY:		

JUL 18 1969