

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPlicate
(Other instructions on
reverse side)

Form approved
Budget Bureau No. 42 R1424.

0349957

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐		5. LEASE DESIGNATION AND SERIAL NO. 10-062368	
2. NAME OF OPERATOR TEXACO Inc.		6. IF INDIAN, ALLOTTEE OR TRIBE NAME -	
3. ADDRESS OF OPERATOR P.O. Box 726, Hobbs, New Mexico 88240		7. UNIT AGREEMENT NAME -	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 3080 990' PUL & 320' PUL, Sec. 19, T-25-N, R-38-E		8. FARM OR LEASE NAME C. D. Penny MCT-4	
		9. WELL NO. 5	
		10. FIELD AND POOL, OR WILDCAT Justis (Ellenburger & McKee)	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 19, 25-N, 38-E	
14. PERMIT NO. Regular	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3085' DP	12. COUNTY OR PARISH Lea	13. STATE N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☒	ABANDON* ☐
REPAIR WELL ☐	CHANGE PLANS ☐
(Other) ☐	

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
(Other) ☐	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Pull tubing & packer.
2. Run tubing w/ squeeze packer & Model "DR" plug.
3. Set "DR" plug in packer @ 7915' & cap w/sand.
4. Set squeeze packer @ 7100' & squeeze McKee perforations 7150' - 7264' w/125 sx Class "C" cmt.
5. Pull tubing & packer.
6. Drill out cement & test casing.
7. Drill out packer & plug.
8. Set RBP @ 7920' & cap w/sand.
9. Perforate w/2 JUMP @ 7040' - 7061'.
10. Run 2-3/8" tubing w/packer set @ 7730' and acidize w/500 gals 15% NHA.
11. Swab & test.
12. Retrieve bridge plug.
13. Return to production.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Assistant District
Superintendent

DATE

5-19-72

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1963—O-685229

847 - 485

RECEIVED
MAY 1963
U.S. GOVERNMENT PRINTING OFFICE
WASHINGTON, D.C.