Form 3160-5 (June 1990)

## UNITED STATES **DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT**

FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 31, 1993

5. Lease Designation and Serial No. LC-030556B SUNDRY NOTICES AND REPORTS ON WELLS 6. If Indian, Allottee or Tribe Name Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. Use "APPLICATION FOR PERMIT-" for such proposals 7. If Unit or CA, Agreement Designation SUBMIT IN TRIPLICATE 1. Type of Well Oil Well Gas 8. Well Name and No. Well Other 2. Name of Operator Stevens B7 #21 Doyle Hartman 9. API Well No. 3. Address and Telephone No. 30-025-22287 P.O. Box 10426, Midland, TX 79702 (915) 684-4011 10. Field and Pool, or Exploratory Area 4. Location of Well (Footage, Sec., T., R., M., or Survey Description) Langlie Mattix (7-R-Q) 1980' FNL, 660' FEL (H) 11. County or Parish, State Section 7, T-23-S, R-37-E Lea Co., NM 12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA TYPE OF SUBMISSION TYPE OF ACTION Notice of Intent Abandonment Change of Plans Recompletion New Construction Subsequent Report Plugging Back Non-Routine Fracturing Casing Repair Water Shut-Off Final Abandonment Notice Altering Casing Conversion to Injection ☐ Dispose Water 13. Describe Proposed or Completed Operations (Clearly state all pertinet details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markders and zones pertinent to this work.)\* 3-25-98 - 4-1/2" casing did not pass casing integrity test. 3-26-98 - Joe Laura approved P&A 3-30-98 - Run 49 joints of 2-3/8" tubing to 1522' mixed and pumped 50 sx of Class C cement down 2-3/8" tubing. Pull 25 joints of 2-3/8" tubing. Mix and pump 50 sx of Class C cement. Cement circulated to surface. Pulled 13 joints of 2-3/8" tubing. Pump cement down 2-3/8" tubing and fill 4-1/2" casing to surface. Total of 110 sx cement. 3-31-98 - Cut off wellhead and install dry hole marker. This well is now plugged and abandoned. Witnessed by Steve Caffey with BLM. What we fortogen? What is TO? Where is top perf.? Where is Top of soil CUV- Mostaymore by CCD.

14. I hereby certify that the foregoing is true and correct Signed	Title Engineer	Date	03/31/98
(This space for Federal or State office use)			
Approved byConditions of approval, if any:	Title	Date	

