

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department  
**OIL CONSERVATION DIVISION**  
P.O. Box 2088

Form C-103  
Revised 1-1-89

DISTRICT I

P.O. Box 1980, Hobbs, NM 88240

DISTRICT II

P.O. Drawer Dd, Artesia, NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec, Nm 87410

Santa Fe, New Mexico 87504-2088

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		API NO. (assigned by OCD on New Wells) <b>30-025-40852-22373</b>	
1. Type of Well: OIL <input checked="" type="checkbox"/> GAS <input type="checkbox"/> WELL <input checked="" type="checkbox"/> WELL <input type="checkbox"/> OTHER <input type="checkbox"/> <b>SDD</b>		5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>	
2. Name of Operator <b>Arch Petroleum, Inc.</b>		6. State Oil & Gas Lease No. <b>16233</b>	
3. Address of Operator <b>10 Desta Drive, Suite 420E Midlnad, Texas 79705</b>		7. Lease Name or Unit Agreement Name <b>E. C. Hill A"</b>	
4. Well Location Unit Letter <b>O</b> : <b>990</b> Feet From The <b>South</b> Line and <b>2310</b> Feet From The <b>East</b> Line Section <b>27</b> Township <b>23S</b> Range <b>37E</b> NMPM <b>Lea</b> County		8. Well No. <b>1</b>	
10. Elevation(Show whether DF, RKB, RT, GR, etc.) <b>3280' GR</b>		9. Pool name or Wildcat <b>SA/Glorietta</b>	

11

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

**NOTICE OF INTENTION TO:**

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

**SUBSEQUENT REPORT OF:**

REMEDIAL WORK ☐ ALTER CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABAN. ☐  
CASING TEST AND CMT JOB ☐  
OTHER: **Temporary Abandonment** ☒

12. Describe Proposed or Completed Operations(Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Set Packer @ 3900'. CIBP @ 5200'.
- 2) Pressure test casing to 360 psi for 30 minutes.  
(Chart attached). Witnessed by OCD. **8/13/97**
- 3) Temporarily abandon wellbore.

*No record of well ever  
having been used as SWD  
Tested to card + computer  
only - did not make sheet*

*This wellbore is to be  
Abandoned as of 8/13/97*

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Robin S. McCarley* TITLE **Technical Assistant**

DATE: **8/26/97**

TYPE OR PRINT NAME **Robin S. McCarley**

TELEPHONE NO. **(915) 685-1961**

APPROVED BY **ORIGINAL SIGNED BY CHRIS WILLIAMS  
DISTRICT I SUPERVISOR**

**SEP 4 1997**

CONDITIONS OF APPROVAL, IF ANY:

DATE

JLTS GB