

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

LAND CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease

State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO OPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT - L" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Argee Oil Company	8. Farm or Lease Name Elson
3. Address of Operator 401 W. Texas, #810, Midland, TX 79701	9. Well No. 1
4. Location of Well UNIT LETTER <u>L</u> , <u>1650</u> FEET FROM THE <u>South</u> LINE AND <u>990</u> FEET FROM THE <u>West</u> LINE, SECTION <u>21</u> TOWNSHIP <u>23S</u> RANGE <u>37E</u> NMPM.	10. Field and Pool, or Wildcat Teague Blinbry
15. Elevation (Show whether DF, RT, GR, etc.) 3296 Gr.	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set cast iron bridge plug @ 5400'. Place 35' cement on CIBP.
2. Set 100 ft. cement plug @ T/San Andres ± 3800'.
3. Set 100 ft. cement plug @ 3000'.
4. Cut 7" @ approximately 1500' and pull.
5. Set 100 ft. cement plug in and out of cut point-tag.
6. Set 100 ft. cement plug 50' in and out of surface csg. (1004-1104) and tag.
7. Set 10 sk plug at surface and place marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R. D. Guenther TITLE Agent DATE 5/27/88

Eddie W. Seay

APPROVED BY Oil & Gas Inspector

TITLE

DATE MAY 31 1988

CONDITIONS OF APPROVAL, IF ANY: