

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPI TE*
(Other instructions on re-
verse side)

Budget Bureau No. 1004-0, 35
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.
LC 030167 A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

McCallister "A"

9. WELL NO.

6

10. FIELD AND POOL OR WILDCAT

Scharborough-Yates 7 Rivers

11. SEC., T., R., W., OR BLK. AND
SURVEY OR AREA

25-26S-36E

12. COUNTY OR PARISH

Lea

13. STATE

N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT..." for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Earl R. Bruno, 915/685-0113

3. ADDRESS OF OPERATOR

P. O. Box 590, Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below)
At surface

1980 ft. FNL and 330 ft. FEL Unit H

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

2940 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

XX

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(Note: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

WORK COMPLETED:

1. Set CIBP at 3100 ft.
2. Load hole with 10# brine and saltwater gel.
3. Pump 5 sackscement on top of CIBP.
4. Cut and pull 2492 ft. - 5 1/2" casing.
5. Load hole with brine and saltwater gel.
6. Pump 35 sacks at 2540 ft., displace and WOC.
7. Tag plug at 2410 ft.
8. Pump 35 sack plug at 1200 ft.
9. Pump 35 sack plug at 550 ft., displace and WOC.
10. Tag plug at 450 ft.
11. Set 10 sack surface plug.
12. Set hole marker.

RECEIVED
NOV 20 1989
BUREAU OF LAND MANAGEMENT
U.S. DEPARTMENT OF THE INTERIOR

18. I hereby certify that the foregoing is true and correct

SIGNED

Jay Morris

TITLE

Agent

DATE

11/20/89

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

11 30 89

CONDITIONS OF APPROVAL, IF ANY:

Approved by
Special Agent in Charge
Bureau of Land Management
U.S. Department of the Interior

*See Instructions on Reverse Side