

UNITED STATES DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Form approved.
Budget Bureau No. 1004-010
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL GAS WELL OTHER

2. NAME OF OPERATOR: Earl R. Bruno 915 685-0113

3. ADDRESS OF OPERATOR: P.O. Box 590 Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)
At surface: 2310 FSL & 330 FEL Unit I

5. LEASE DESIGNATION AND SERIAL NO.: LC 030167 b ✓

6. IF INDIAN, ALLOTTEE OR TRIBE NAME:

7. UNIT AGREEMENT NAME:

8. FARM OR LEASE NAME: McCallister B ✓

9. WELL NO.: #1 ✓

10. FIELD AND POOL OR WILDCAT: 7 Rivers
Scharborough-Yates

11. SEC., T., R., W., OR BLK. AND SURVEY OR AREA: 25-26S-36E ✓

12. COUNTY OR PARISH: Lea

13. STATE: N.M.

14. PERMIT NO.: 2939 DF

15. ELEVATIONS (Show whether DF, RT, GR, etc.):

10. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT OFF	PULL OR ALTER CASING	WATER SHUT-OFF	REPAIRING WELL
FRACTURE TREAT	MULTIPLE COMPLETION	FRACTURE TREATMENT	ALTERING CASING
SHOOT OR ACIDIZE	ABANDON*	SHOOTING OR ACIDIZING	ABANDONMENT*
REPAIR WELL	CHANGE PLANE	(Other)	(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- It is proposed to P&A as follows:
- * NU BOP.
 - 1. Set CIBP @ 3100 & cap with 20' cement → 35'
 - 2. Load hole with 10 ppg brine with 25# salt gel / bbl
 - 3. Cut casing @ free point
 - 4. Set 35 SX stub plug (50' in & out)(TAG)
 - 5. Set 35 SX plug from 1100-1200
 - 6. Set 35 SX plug from 459-559 (TAG)
 - 7. Set 10 SX surface plug
 - 8. Erect marker

*NOTE: casing stub may be at top of salt rather than at base of salt. If this is so, no plug will be set @ 1100'-1200' since the stub plug should cover it.

SJS

18. I hereby certify that the foregoing is true and correct

SIGNED: Jim Gray J.E. Gray TITLE: Engineer DATE: 8-7-89

(This space for Federal or State office use)

APPROVED BY: TITLE: DATE:

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side