

Form 5000-7
(June 1990)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

APR 7

11 00 AM '95

COMMISSION
BUREAU 88140
FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993
5. Lease Designation and Serial No.
LC-030556 (A)
6. If Indian, Allottee or Tribe Name

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well ☒ Oil Well ☐ Gas Well ☐ Other	8. Well Name and No. Stevens A-34 #3
2. Name of Operator Lewis B. Burleson, Inc.	9. API Well No. 30-025-23845
3. Address and Telephone No. P.O. Box 2479 Midland, Texas 79702	10. Field and Pool, or Exploratory Area Jalmat (T-Y-7R)
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) Unit F 1980 FNL 1650 FWL Sec. 34, T-23-S R-36-E	11. Country or Parish, State Lea NM

CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
☐ Notice of Intent	☒ Abandonment
☒ Subsequent Report	☐ Recompletion
☐ Final Abandonment Notice	☐ Plugging Back
	☐ Casing Repair
	☐ Altering Casing
	☐ Other
	☐ Change of Plans
	☐ New Construction
	☐ Non-Routine Fracturing
	☐ Water Shut-Off
	☐ Conversion to Injection
	☐ Dispose Water

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- 3/14/95 1) Set 5 1/2" CIBP @ 3343' w/5 sack cement cap.
2) Circulate hole with mud laden fluid.
3) Cut 5 1/2" casing at 2300' and pull.
3/15/95 4) RIH with tubing to 2350'. Mix and pump 15 sack class C cement plug.
Tag plug at 2000'.
5) RIH with tubing to 1500'. Mix and pump 40 sack class C cement plug.
Tag plug at 1500'.
3/16/95 6) Mix and pump 40 sack plug. Tag at 1500'.
7) Mix and pump 40 sack plug. Tag at 1496'.
8) Mix and pump 65 sack plug. Tag at 1450'.
9) Mix lem and 50 sack plug. Tag at 1388'.
10) RIH with tubing to 478'. Mix and pump 40 sack class C cement plug.
Tag at 350'.
11) RIH with tubing to 50'. Mix and pump 15 sacks class C cement plug
to surface.
3/17/95 12) Install marker. Clean location.

Approved as to plugging of the well bore
Company under bond is retained until
well restoration is completed.

14. I hereby certify that the foregoing is true and correct

Signed <i>[Signature]</i>	Title Field Supervisor	Date 4-5-95
(This space for Federal or State office use)		
Approved by <i>[Signature]</i>	Title <i>[Signature]</i>	Date 5/4/95
Conditions of approval, if any		

Take notice that, under 18 U.S.C. 1001, it is a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statement or representation as to any matter within its jurisdiction.

*See Instruction on Reverse Side