

November 1983)
Formerly 9-331)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

EXPIRATION DATE
(Other instructions on re-
verse side)

Expires August 31, 1985
5. LEASE DESIGNATION AND SERIAL NO.

NM LCO 62269-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Graham Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Double X Delaware

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 22

T-24-S, R-32-E

12. COUNTY OR PARISH

Lea

13. STATE

NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Ralph E. Williamson

3. ADDRESS OF OPERATOR

P.O. Box 16 Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

660' FSL & 1980' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether CP, RT, GR, etc.)

3593 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*

01-30-86

- 1) RU unit, Set CIBP @ 4500' and put 35' cement on same.
- 2) GIH w/cutter, shot pipe @ 4000'.
- 3) GIH w/bull plug, 4'x2 3/8" perforating sub. RU Western, set 100' plug @ 4000'.
- 4) Tag plug after let set 3 hrs.
- 5) Set perfg. sub @ 2825'
- 6) Set 100' plug @ 2825'
- 7) Pulled tbg. to 1080', set 100' plug.
- 8) Pulled tbg. to 404', set 100' plug.
- 9) Tag plug @ 300', COH w/tbg., cut off & 5/8" head.
- 10) Set 50' surface plug, erected dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Production

DATE

02-04-86

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

37

RECEIVED
FEB -6 1986
O.C.D.
HOBBS OFFICE