

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-7

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Sun Exploration & Production Co.	8. Farm or Lease Name S.R. Cooper
3. Address of Operator P.O. Box 1861, Midland, TX 79702	9. Well No. 4
4. Location of well UNIT LETTER <u>G</u> <u>2310</u> FEET FROM THE <u>North</u> LINE AND <u>2310</u> FEET FROM <u>East</u> LINE, SECTION <u>23</u> TOWNSHIP <u>24S</u> RANGE <u>36E</u> N.M.P.M.	10. Field and Pool, or Wildcat Jalmat
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

MIRU. Install BOP. POH w/ tbg and REDA Pump.

RIH w/ RBP on WL and set at 3134. *Casing collars at: 3042', 3069½', 3101½', 3125½', 3154½', 3185'.

RIH w/ 2-3/8 tbg, RDG pkr & retrieving head. Tag RBP @ 3134. Set pkr & test RBP to 500 psi. PU & set pkr @ 3050'. Swab. Determine FE and content. If swab results are favorable, retrieve RBP and POH w/ tbg, pkr, & RBP. Set CIBP at 3134 on WL. RIH w/ tbg and pkr. Tag CIBP. Set pkr and test CIBP to 500 psi. POH.

Pumping instructions will be issued based on swab results.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Dee Ann Kemp TITLE Associate Accountant DATE July 20, 1984

ORIGINAL SIGNED BY JOHN BENTON

APPROVED BY DISTRICT SUPERVISOR TITLE DATE JUL 27 1984

CONDITIONS OF APPROVAL, IF ANY: