

U. S. GEOLOGICAL SURVEY
P. O. Box 1157
Hobbs, New Mexico 88240

HOBBS DISTRICT

Herman J. Ledbetter
No. 1 Jay Federal
NE $\frac{1}{4}$ NE $\frac{1}{4}$ sec. 24-26S-37E
Lea County, N. M.

Above Data Required on Well Sign

CONDITIONS OF APPROVAL

1. Drilling operations authorized are subject to the attached sheet for general requirements for drilling and producing operations.
2. Notify this office (telephone (505) 393-3612) when the well is spudded and in sufficient time for a representative to witness cementing operations. After hours & weekends, call C. L. Coshaw 393-8244.
3. Immediate notice is required of all blowouts, fires, spills, and accidents involving life-threatening injuries or loss of life.
4. Secure prior approval before changing the approved drilling program or commencing plugging operations, plug-back work, casing repair work, or corrective cementing operations.
5. Blowout prevention equipment is to be installed, tested, and in working order before drilling below the surface casing and shall be maintained ready for use until drilling operations are completed.
6. A kill-line is to be properly installed and is not to be used as a fill-up line.
7. Blowout preventers are to have proper casing rams when running casing.
8. Drill string safety valve(s) to fit all pipe in the drill string to be maintained on the rig floor while drilling operations are in progress.
9. Blowout prevention drills are to be conducted as necessary to assure that equipment is operational and that each crew is properly trained to carry out emergency duties. All BOP tests and drills are to be recorded on the driller's log.
10. Minimum required fill of cement behind the 4 $\frac{1}{2}$ " casing is to the base of the salt section.
11. 8-5/8" surface casing should be set in the Rustler Anhydrite formation and cement circulated to the surface. If surface casing is set at a lesser depth, the 4 $\frac{1}{2}$ " casing must be cemented from the casing shoe to the surface, or cemented to the surface through a stage tool set at least 50 feet below the top of the Rustler, after cementing around the shoe with the specified amount of cement.
12. Choke manifold must be installed.

RECEIVED

NOV 16 1976

OIL CONSERVATION COMM.
HOBBS, N. M.