

1. MIRU. Circ hole w/10# brine. POH w/2-7/8" tbg & seal assembly.
2. RIH w/spear, bumper sub, hydraulic jars, DC's & 2-7/8" tbg. Fished RLA.
3. LD fishing tools, DC's & PBR assembly.
4. CIBP on WL set @ 14,766.
5. RIH w/tbg. Tag CIBP. Circ hole w/10# mud laden brine. Spot 75 sx C1 H cmt plug on top of CIBP @ 14,766'. Cmt on top of plug @ 14,666'.
6. TIH to tag cmt plug. Plug not in liner. CIBP set @ 14,848'. Circ hole with mud laden brine. Set 4-1/2" CIBP on WL @ 14,700'. RIH w/tbg. Tagged CIBP @ 14,708'.
7. Circ hole w/gel & 10# brine. Pmpd cmt plug on CIBP @ 14,708'. Pmpd 40 sx plug @ 13,930'. POH w/tbg.
8. Run 7" CIBP & set @ 12,575'. Dumped 35' cmt on top of plug. RU WL & ran a nitro shot to 4974'. Shot 7" csg w/nitro @ 4613'. LD 7" csg.
9. TIH w/2-7/8" tbg OE. Spot 40 sx plug @ 5025'. POH to 4663'. Spot 50 sx plug. Pulled tbg to 1680'. Spot 40 sx plug. TOH.
10. Tag cmt plug @ 1440'. Pull tbg to 650'. Spot 40 sx cmt plug. Pulled tbg to 70'. Spot 30 sx. Cmt plug to surf. Cut off csg head. Weld plate on csg stub. Install marker & released rig. Well plugged & abandoned 8-27-87.