

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-28471
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. 26-3620
7. Lease Name or Unit Agreement Name State NNG
8. Well No. 2
9. Pool name or Wildcat East Mason Delaware
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3156 GL

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator
Tempo Energy, Inc.

3. Address of Operator
4000 N. Big Spring, Suite 104 Midland, Texas 79702

4. Well Location
Unit Letter M : 990 Feet From The South Line and 330 Feet From The West Line

Section 16 Township 26S Range 32-E NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
3156 GL

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

9/4/91 Plug # 1 Spot 25 SXS Cement Plug @ 4300 Ft. WOC
9/5/91 Plug # 2 Tag Plug @ 4196 Ft. Circ. hole with 10# Brine with 25# Salt Gel per BB
9-5-91 Plug # 3 Cut 5-1/2" Casing @ 2970' Lay down casing.
9-6-91 Plug # 4 RIH with tubing to 3020 ft. spot 40 SXS Plug. WOC tag plug @ 2940
9-7-91 Plug # 5 Spot 40 SXS @ 1431 ft. WOC
9-9-91 Plug # 6 RIH with tubing & tag plug @ 1306 ft.
9-9-91 Plug # 7 Spot 40 SXS plug @ 300 Ft. 10 SXS @ Surf.
Install dry hole marker

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE Acquisition Manager DATE Sept. 14, 1991

TYPE OR PRINT NAME _____ TELEPHONE NO. _____

(This space for State Use)

APPROVED BY [Signature] TITLE Head DATE 2-27-03

CONDITIONS OF APPROVAL, IF ANY: